



GTEC UPS MODEL:

# **DISCOVERY**

Alarm codes

## **SERVICE DOCUMENT**

# 1 Status/alarm codes

The UPS is able to monitor and report on the display panel the working status and any anomalies or faults that may occur during operation. If there is a problem, the UPS reports the event by displaying the appropriate code and the type of active alarm on the display panel.

## 1.1 Status

The *Status codes* indicate the current working status of the UPS.

CODE	MESSAGE	DESCRIPTION	NOTE
S00	INITIALISATION	Activation of the UPS (from UPS completely no powered)	(1)
S01	AUTOTEST	Autotest in progress	(1)
S02	AUTOCALIBRATION	Autocalibration in progress	(1)
S03	SIGNAL TEST	Signal test in progress	(1)
S04	FUNCTIONAL TEST	Functional test in progress	(1)
S05	WAIT CABINET ID	Waiting for cabinet identification number ID	(1)
S06	STAND-BY WITH CB OFF	UPS in standby (Load not powered) with battery charger OFF	
S07	LOCK STAND-BY AND CB OFF	UPS locked in standby (Load not powered) with battery charger OFF	
S10	PRECHARGE	Precharge from mains in progress	
S11	PRECHARGE FROM BATTERY	Precharge from battery in progress	
S20	POWER OFF ACTIVE	UPS not powered and consequently powering off.	
S21	STAND-BY WITH CB ON	UPS in standby (Load not powered) with battery charger ON	
S22	LOCK STAND-BY AND CB ON	UPS locked in standby (Load not powered) with battery charger ON	
S30	WAIT RECHARGE BATTERY	Waiting to recharge the battery before starting	
S31	CALIBRATION	Calibration mode active	
S32	STARTING	Start-up in progress	
S40	ONLINE	Online mode active	
S41	ONLINE/ECM	RESERVED/NOT USED	
S42	ECO	Economy mode active	
S43	ECO+	RESERVED/NOT USED	
S44	ACTIVE ECO	RESERVED/NOT USED	
S45	FREQUENCY CONVERTER	Frequency converter mode active	

S46	FREQUENCY CONV./ECM	RESERVED/NOT USED	
S47	READY FOR EMERGENCY	Stand-by off mode active	
S50	BATTERY WORKING	Battery operation	
S51	BATTERY WORKING FORCED	Battery operation forced by command	
S52	BATTERY LOW	Battery low voltage	
S60	TEMPORARY BYPASS	Load powered temporary from bypass line	
S61	BYPASS DUE TO INV. LOCK	Load powered from bypass line due to inverter lock	
S62	LOAD FORCED ON BYPASS	Load powered from bypass line forced by command	
S63	REMOTE BYPASS COMMAND	Remote command active to power the load by bypass line (from input contact)	
S64	MANUAL BYPASS ACTIVE	Manual bypass active	
S65	BYPASS DUE TO BAT. ENDED	Load powered from bypass line due to battery autonomy ended	
S70	TEMPORARY INVERTER	Load powered temporary by inverter	
S71	INVERT. DUE TO BYP. LOCK	Load powered by inverter due to bypass line locked	
S72	LOAD FORCED ON INVERTER	Load powered by inverter forced by command	
S80	POWER CIRCULATION	Power circulation active (on SBYP or on MBYP)	
S81	POWER CIRCUL. BATTERY	RESERVED/NOT USED	
S90	LOAD OFF	Load not powered	
S91	EMERGENCY POWER OFF	Emergency Power Off (EPO) active	
S92	DISCONNECT. FROM THE LOAD	UPS disconnected from the load	

## 1.2 Command

The *Command codes* indicate the presence of an active command.

CODE	MESSAGE	DESCRIPTION	NOTE
C01	REMOTE OFF COMMAND	Remote command active to switch off the UPS (from input contact)	
C02	REMOTE BYPASS COMMAND	Remote command active to power the load by bypass line (from input contact)	
C03	REMOTE ON COMMAND	Remote command active to switch on the UPS (from input contact)	
C04	BATTERY TEST ACTIVE	Battery test running	
C05	MANUAL BYPASS COMMAND	Manual bypass active	
C06	EMERGENCY OFF COMMAND	Emergency switch-off command active (REPO)	
C07	REMOTE BATT. CHARGER OFF	Remote command to switch off the battery charger (from input contact)	
C08	BYPASS COMMAND ACTIVE	Command active to power the load by the bypass line (from the panel)	

## 1.3 Warning

The *Warning codes* are messages related to a special configuration or to a particular operation of the UPS.

CODE	MESSAGE	DESCRIPTION	NOTE
W01	BATTERY LOW WARNING	End of discharge pre-alarm	
W02	SHUTDOWN ACTIVE	Programmed switch-off active	
W03	SHUTDOWN IMMINENT	Programmed switch-off imminent	
W04	BYPASS DISABLED	Bypass disabled (the bypass will not be used in any condition)	
W05	SYNCHRONISATION DISABLED	Synchronisation disabled (UPS in Free running mode)	
W06		NOT USED	
W07	SERVICE UPS	Maintenance of the UPS must be performed	
W08	SERVICE BATTERY	Maintenance of the batteries must be performed	

## 1.4 Anomaly

The *Anomaly codes* indicate conditions or problems which do not involve a UPS block but could limit or prevent the use of certain features.

CODE	MESSAGE	DESCRIPTION	NOTE
A01	CONFIG. DATA CORRUPTED	Configuration data not valid (i.e.: battery charger not properly configured)	
A02	DISPLAY ERROR	Display communication lost	
A03	INVERTER ASYNCHRONOUS	Inverter not synchronised with the bypass line	
A04	EXTERNAL SYNC OUT OF RANGE	External Sync out of tolerance range	
A05	MAINS OVERVOLTAGE L1	Overvoltage on input line Phase1	
A06	MAINS OVERVOLTAGE L2	Overvoltage on input line Phase2	
A07	MAINS OVERVOLTAGE L3	Overvoltage on input line Phase3	
A08	MAINS UNDERVOLTAGE L1	Undervoltage on input line Phase1	
A09	MAINS UNDERVOLTAGE L2	Undervoltage on input line Phase2	
A10	MAINS UNDERVOLTAGE L3	Undervoltage on input line Phase3	
A11	MAINS FREQUENCY ABNORMAL	Input frequency out of tolerance	
A12	INPUT SWITCH OPEN	Auxiliary contact of the input switch open (from input contact)	
A13	BYPASS VOLTAGE ABNORMAL L1	Voltage on bypass line out of tolerance Phase1	
A14	BYPASS VOLTAGE ABNORMAL L2	Voltage on bypass line out of tolerance Phase2	
A15	BYPASS VOLTAGE ABNORMAL L3	Voltage on bypass line out of tolerance Phase3	
A16	BYPASS FREQUENCY ABNORMAL	Bypass frequency out of tolerance	
A17	BYPASS SWITCH OPEN	Auxiliary contact of the bypass switch open (from input contact)	
A18	BYPASS VOLT. OUT OF RANGE	Voltage on bypass line not present	
A19	OUTPUT PEAK OVERCURRENT L1	RESERVED/NOT USED	
A20	OUTPUT PEAK OVERCURRENT L2	RESERVED/NOT USED	
A21	OUTPUT PEAK OVERCURRENT L3	RESERVED/NOT USED	
A22	LOAD > USER THRESHOLD L1	Load higher than the user threshold set on Phase1	
A23	LOAD > USER THRESHOLD L2	Load higher than the user threshold set on Phase2	
A24	LOAD > USER THRESHOLD L3	Load higher than the user threshold set on Phase3	
A25	OUTPUT SWITCH OPEN	Auxiliary contact of the output switch open (from input contact)	
A26	BATTERY NOT PRESENT B+	Positive branch batteries missing or battery fuses open	
A27	BATTERY NOT PRESENT B-	Negative branch batteries missing or battery fuses open	
A28		NOT USED	
A29	SYSTEM TEMP. SENSOR FAULT	System temperature sensor fault	

CODE	MESSAGE	DESCRIPTION	NOTE
A30	SYSTEM UNDERTEMPERATURE	System temperature <0°C	
A31	SYSTEM OVERTEMPERATURE	System temperature >50°C	
A32	BOOST UNDERTEMPERATURE	PFC/Boost/CB stage temperature <0°C	
A33	INVERTER UNDERTEMPERATURE	Inverter stage temperature <0°C	
A34		NOT USED	
A35	BATTERY TEMP. SENSOR FAULT	RESERVED/NOT USED	
A36	BATTERY OVERTEMPERATURE	Internal battery over temperature	
A37	EXTERNAL TEMP. SENS. FAULT	External battery temperature sensor fault	
A38	EXTERNAL SENSOR OVERTEMP.	External sensor temperature >33°C (adjustable with the service software)	
A39	REPLACE BATTERY B+	Replace the positive branch batteries	
A40	REPLACE BATTERY B-	Replace the negative branch batteries	
A41	QN SWITCH OPEN	RESERVED/NOT USED	
A42	BATTERY SWITCH OPEN	Auxiliary contact of the battery switch open (from input contact)	
A43	ALARM FROM INPUT CONTACT	General alarm from external contact (from input contact)	
A44	MAINS VOLTAGE OUT OF RANGE	Mains voltage fail on phase 1, phase 2 and phase 3 of input line	
A45	LOAD > CSS LIMIT	Overload level achievement referred to the power according to the EN50171 standard (only for CBT/CBM)	
A46	DEEP DISCHARGE PROTECTION	Battery low level achievement during the last battery intervention (only for CBT/CBM)	
A47	DIFFERENT FIRMW. VERSION	UPS in a parallel system with different firmware version	(2)
A48	ANOMALY ON REMOTE UNIT	RESERVED/NOT USED	
A49	DATE AND TIME NOT SET	The date and time are not set	
A50	CALIBRATION DATA ERROR A	Calibration parameters out of range	
A51	CALIBRATION DATA ERROR B	RESERVED/NOT USED	
A52	OUTPUT BOARD DATA ERROR	Output board version not compatible with control	

## 1.5 Fault

The *Fault codes* indicate critical problems that, if persisting, can lead to the block of the UPS even in a very short time.

CODE	MESSAGE	DESCRIPTION	NOTE
F01	INTERNAL COMM. ERROR	Internal communication error	
F02	MAINS PHASE REVERSED	Incorrect cycle of the input phases	
F03	INP. FUSE/CONTACT FAULT L1	Phase1 input fuse blown or input contact fault (does not close)	
F04	INP. FUSE/CONTACT FAULT L2	Phase2 input fuse blown or input contact fault (does not close)	
F05	INP. FUSE/CONTACT FAULT L3	Phase3 input fuse blown or input contact fault (does not close)	
F06	INPUT CONTACT SHORT CCT L1	Phase1 input contact locked short-circuit (does not open)	
F07	INPUT CONTACT SHORT CCT L2	Phase2 input contact locked short-circuit (does not open)	
F08	INPUT CONTACT SHORT CCT L3	Phase3 input contact locked short-circuit (does not open)	
F09	PRECHARGE DC BUS ERROR B+	Pre charge of the positive capacitor branch failed	
F10	PRECHARGE DC BUS ERROR B-	Pre charge of the negative capacitor branch failed	
F11	BOOST FAULT	Boost stage anomaly	
F12	BYPASS PHASE REVERSED	Incorrect cyclical direction of the bypass phases	
F13	BOOST VOLTAGE ERROR	Temporary overvoltage boost	
F14	INV. SINEWAVE ABNORMAL L1	Phase1 sinusoid inverter deformed	
F15	INV. SINEWAVE ABNORMAL L2	Phase2 sinusoid inverter deformed	
F16	INV. SINEWAVE ABNORMAL L3	Phase3 sinusoid inverter deformed	
F17	INVERTER ERROR	Inverter stage anomaly	
F18	OUTPUT VDC BALANCE ERROR	Balance error on output VDC	
F19	BATTERY OVERVOLTAGE B+	Overvoltage of the positive battery branch (battery charger error)	
F20	BATTERY OVERVOLTAGE B-	Overvoltage of the negative battery branch (battery charger error)	
F21	BATTERY UNDERVOLTAGE B+	Undervoltage/fault of the positive battery branch (battery/fuse)	
F22	BATTERY UNDERVOLTAGE B-	Undervoltage/fault of the negative battery branch (battery/fuse)	
F23	OUTPUT OVERLOAD	Output overload	
F24	BYPASS NOT AVAILABLE	RESERVED/NOT USED	
F25	OUTPUT NEGATIVE POWER	Inverter takes power from output	
F26	OUT. CONTACT SHORT CCT L1	Phase1 output contact locked (does not open)	
F27	OUT. CONTACT SHORT CCT L2	Phase2 output contact locked (does not open)	
F28	OUT. CONTACT SHORT CCT L3	Phase3 output contact locked (does not open)	
F29	OUT.FUSE/CONTACT FAULT L1	Phase1 output fuse blown or output contact fault (does not close)	

CODE	MESSAGE	DESCRIPTION	NOTE
F30	OUT.FUSE/CONTACT FAULT L2	Phase2 output fuse blown or output contact fault (does not close)	
F31	OUT.FUSE/CONTACT FAULT L3	Phase3 output fuse blown or output contact fault (does not close)	
F32	BATTERY CHARGER FAULT	Battery charger stage fault	
F33	BATTERY MEASURES ERROR	Failure of the system to measure the battery voltage	
F34	POWER MODULE OVERTEMP.	Power module heatsink temperature >100°C (>85°C for S3U)	
F35	TRANSFORMER OVERTEMP.	Over temperature of the transformer	(3)
F36	FAN FAULT	RESERVED/NOT USED	
F37	BATTERY CHARGER OVERTEMP.	Battery charger temperature >85°C (only for S3U)	
F38		NOT USED	
F39	VDC BUS MEASURES ERROR	Failure of the system to measure the DC bench voltage	
F40	BATTERY FUSE 1 B+	Fuse of the CB positive branch blown	
F41	BATTERY FUSE 1 B-	Fuse of the CB negative branch blown	
F42	BATTERY FUSE 2 B+	Fuse of the boost positive branch blown	
F43	BATTERY FUSE 2 B-	Fuse of the boost negative branch blown	
F44		NOT USED	
F45	PARALLEL LINK OPEN	Communication bus open in a parallel system (one point)	(2)
F46	PARALLEL R_BYP. LINE FAULT	Anomaly of bypass request line in a parallel system	(2)
F47	PARALLEL SYNC. LINE FAULT	Anomaly of synchronization line in a parallel system	(2)
F48	BATTERY POLARITY ERROR	Wrong position of neutral battery cable	
F49	BATT. CONTACT 1 CMD FAULT	Fault in the signal command of the battery contact 1	
F50	BATT. CONTACT 2 CMD FAULT	Fault in the signal command of the battery contact 2	
F51	BATT. CONTACT 1 SHORT CCT	Short-circuit on battery contact 1	
F52	BATT. CONTACT 2 SHORT CCT	Short-circuit on battery contact 2	
F53	BYP. AUXILIARY POWER FAULT	Fault of the redundant auxiliary power supply for bypass line	
F54	MEMORY ACCESS ERROR A	Memory (A) access error	
F55	MEMORY ACCESS ERROR B	RESERVED/NOT USED	
F56	CALIBRATION ERROR PFC	PFC calibration error	
F57	CALIBRATION ERROR INV	Inverter calibration error	
F58	CALIBRATION ERROR BAT	Battery calibration error	
F59	OUTPUT BOARD. COMM. ERROR	Output board communication error	
F60	COMM. BOARD LINK FAULT	Communication board link fault	
F61	CALIBRATION ERROR BYP	Bypass calibration error	



## 1.6 Lock

The *Lock codes* indicate that the UPS or a part thereof is blocked (they are usually preceded by an alarm alert). In the event of the failure and consequent block of the inverter, this will switch off along with the power to the load through the bypass line (this procedure is excluded for the blocks due to persistent overloads and blocks due to short circuits).

CODE	MESSAGE	DESCRIPTION	NOTE
L01	AUXILIARY POWER FAULT	Auxiliary power supply incorrect	
L02	BOARDS LINK FAULT	Disconnection of one or more internal connection cable of the boards	
L03	INP. FUSE/CONTACT FAULT L1	Phase1 input fuse blown or input contact does not close	
L04	INP. FUSE/CONTACT FAULT L2	Phase2 input fuse blown or input contact does not close	
L05	INP. FUSE/CONTACT FAULT L3	Phase3 input fuse blown or input contact does not close	
L06	BOOST OVERVOLTAGE B+	Boost positive stage overvoltage	
L07	BOOST OVERVOLTAGE B-	Boost negative stage overvoltage	
L08	BOOST UNDERVOLTAGE B+	Boost positive stage undervoltage	
L09	BOOST UNDERVOLTAGE B-	Boost negative stage undervoltage	
L10	BYPASS BACKFEED	Bypass static switch fault (Back Feed Protection)	
L11	BYPASS OUTPUT FAULT L1	L1 bypass output unavailable for contact fault	
L12	BYPASS OUTPUT FAULT L2	L2 bypass output unavailable for contact fault	
L13	BYPASS OUTPUT FAULT L3	L3 bypass output unavailable for contact fault	
L14	INVERTER OVERVOLTAGE L1	Phase1 inverter overvoltage	
L15	INVERTER OVERVOLTAGE L2	Phase2 inverter overvoltage	
L16	INVERTER OVERVOLTAGE L3	Phase3 inverter overvoltage	
L17	INVERTER UNDERVOLTAGE L1	Phase1 inverter undervoltage	
L18	INVERTER UNDERVOLTAGE L2	Phase2 inverter undervoltage	
L19	INVERTER UNDERVOLTAGE L3	Phase3 inverter undervoltage	
L20	INV. SINEWAVE ABNORMAL L1	Direct voltage in inverter output or deformed inverter sinusoid of Phase1.	
L21	INV. SINEWAVE ABNORMAL L2	Direct voltage in inverter output or deformed inverter sinusoid of Phase2.	
L22	INV. SINEWAVE ABNORMAL L3	Direct voltage in inverter output or deformed inverter sinusoid of Phase3.	
L23	OUTPUT OVERLOAD L1	Overload on Phase1 output	
L24	OUTPUT OVERLOAD L2	Overload on Phase2 output	
L25	OUTPUT OVERLOAD L3	Overload on Phase3 output	
L26	OUTPUT SHORT-CIRCUIT L1	Short-circuit on Phase1 output	

CODE	MESSAGE	DESCRIPTION	NOTE
L27	OUTPUT SHORT-CIRCUIT L2	Short-circuit on Phase2 output	
L28	OUTPUT SHORT-CIRCUIT L3	Short-circuit on Phase3 output	
L29	OUTPUT FUSE/CONTACT FAULT L1	Phase 1 output fuse blown or output contact fault (does not close)	
L30	OUTPUT FUSE/CONTACT FAULT L2	phase 2 output fuse blown or output contact fault (does not close)	
L31	OUTPUT FUSE/CONTACT FAULT L3	Phase 3 output fuse blown or output contact fault (does not close)	
L32	PARALLEL SYNCHRON. ERROR	Synchronisation error in a parallel system	(2)
L33	PARALLEL SYNC. LINE FAULT	Synchronisation signal anomaly in a parallel system	(2)
L34	BOOST OVERTEMPERATURE	PFC/Boost/CB stage temperature >105°C (>90°C for S3U)	
L35	INVERTER OVERTEMPERATURE	Inverter stage temperature >105°C (>90°C for S3U)	
L36		NOT USED	
L37	BATTERY CHARGER OVERTEMP.	Battery charger temperature >90°C (only for S3U)	
L38	BOOST TEMP. SENSOR FAULT	Temperature sensor of the boost stage fault	
L39	INVERTER TEMP. SENSOR FAULT	Temperature sensor of the inverter stage fault (short-circuit or open-circuit)	
L40		NOT USED	
L41	BATT. CHARGER TEMP. SENSOR	Battery charger temperature sensor fault (only for S3U)	
L42	BATTERY FUSE FAULT	Battery fuse blown	
L43	BATTERY CONTACT SHORT CCT	Battery contact locked short-circuit (does not open)	
L44	INPUT CONTACT SHORT CCT L1	Phase 1 input contact locked short-circuit (does not open)	
L45	PARALLEL BUS DIVISION	Communication bus interrupted in a parallel system (two points)	(2)
L46	PARAL. COMMUNICATION FAULT	Communication bus anomaly in a parallel system	(2)
L47	PARALLEL BOARD FAULT	Parallel board anomaly	(2)
L48	BATTERY POLARITY ERROR	RESERVED/NOT USED	
L49	OUTPUT CAPACITOR OVERTEMP.	Output AC capacitor fault	
L50	BYPASS OVERTEMP.	Bypass over temperature	(3)
L51	BATT. CHARGER SHORT-CIRCUIT	Short-circuit on battery charger output	
L52	PARAL. P POWER ERROR L1	Active power error for the phase 1	(2)
L53	PARAL. P POWER ERROR L2	Active power error for the phase 2	(2)
L54	PARAL. P POWER ERROR L3	Active power error for the phase 3	(2)
L55	PARAL. Q POWER ERROR L1	Reactive power error for the phase 1	(2)
L56	PARAL. Q POWER ERROR L2	Reactive power error for the phase 2	(2)

CODE	MESSAGE	DESCRIPTION	NOTE
L57	PARAL. Q POWER ERROR L3	Reactive power error for the phase 3	(2)

### 1.7 Additional events (only for history)

The *Additional events Codes* indicates events useful for history of the UPS. Since are instantaneous, they don't appear on the display but are logged in the log file.

CODE	MESSAGE	DESCRIPTION	NOTE
E01	ON FOR AUTO-RESTART	Automatic switching on of the UPS (due to auto-restart function) at the coming back of the mains, after a shutdown executed in battery working mode.	(1)
E02	ON FOR RESTORE COMMAND	Switching on of the UPS because of software command (received via serial line or via network card).	(1)
E03	OFF FOR AUTO-OFF	UPS switched off because of load under minimum threshold value	(1)
E04	OFF FOR SHUTDOWN COMMAND	UPS switched off because of software command (received via serial line or via network card).	(1)
E05	OFF FOR BATTERY ENDED	UPS switched off because of battery fully discharged.	(1)
E06	OFF FOR AUTONOMY LIMITAT.	UPS switched off because of limited autonomy setting	(1)
E07	OFF FOR LOCK	UPS switched off because of lock	(1)
E08	POWER ON	UPS powered on	(1)
E09	BATTERY CHARGED	UPS battery charged	(1)
E10	CONFIGURATION CHANGED	Configuration of the UPS changed from the panel	(1)
E11	ON FOR SYSTEM ON	UPS switched on by the panel	(1)
E12	OFF FOR SYSTEM OFF	UPS switched off by the panel	(1)
E13	BATTERY WORKING	UPS switched in battery working status	(1)
E14	LOAD ON BYPASS	Load switched on bypass	(1)

### 1.8 NOTE

- (1) = Only for log file
- (2) = Only for parallel system
- (3) = Only for special UPS