



GTEC UPS MODEL:

**SATURN 60 – 100 kVA**

**SERVICE MANUAL**



## Contents

<b>1</b>	<b>INTRODUCTION</b>	<b>4</b>
<b>2</b>	<b>SOFTWARE OPERATIONS</b>	<b>5</b>
2.1	SAVING THE UPS LOG FILE	5
2.2	CONFIGURING THE UPS	5
2.3	UcomGp SOFTWARE	5
2.4	UPDATING THE FIRMWARE	5
<b>3</b>	<b>SWITCHING THE UPS ON/OFF</b>	<b>6</b>
3.1	SWITCHING OFF THE UPS WHILST DELIVERING POWER TO THE LOAD	6
3.2	SWITCHING OFF THE UPS WHILST CUTTING OFF THE POWER SUPPLY TO THE LOAD	6
3.3	RESTARTING THE UPS	6
3.4	STARTING THE UPS FROM THE BATTERY	6
3.5	ADDITIONAL SERVICE OPERATIONS	6
<b>4</b>	<b>UPS INTERNAL STRUCTURE</b>	<b>7</b>
4.1	DISCONNECTION SWITCH POSITIONS	7
4.2	BOARD /COMPONENT POSITIONS INSIDE THE UPS.	10
4.3	UPS BLOCK DIAGRAM	16
4.4	SINGLE PHASE BLOCK DIAGRAM	17
<b>Legend:</b>		<b>17</b>
4.5	SINGLE PHASE ELECTRICAL DIAGRAM	18
4.6	FAN POWER SUPPLY CONNECTION	19
<b>5</b>	<b>AUXILIARY POWER SUPPLY FAILURE (L01)</b>	<b>20</b>
5.1	TESTS	20
5.2	15V - LEM POWER SUPPLY	21
5.3	12V POWER SUPPLY - ANALOGUE PART OF CONTROL BOARD	21
5.4	24V POWER SUPPLY FOR FANS (regulated)	22
5.5	24V EMERGENCY POWER SUPPLY FOR FANS (fault B0102)	22
5.6	HF 50KHz POWER SUPPLY FOR BATTERY AND BYPASS SCR	23
5.7	HF 100KHz POWER SUPPLY FOR POWER STAGES AND RS232	23
5.8	"AUX KO" (L01) DETECTION LOGIC	24
5.9	CHECK AUX VOLTAGE (L01)	25
5.10	MAIN POWER SUPPLY UNIT FAILURE	26
5.11	MICRO DSP / CONTROL BOARD FAILURE	27
5.12	BOARD RS232 FAILURE	28
5.13	FAN FAILURE	28
<b>6</b>	<b>COMPONENT TEST FOLLOWING A FAILURE</b>	<b>29</b>
6.1	BOOST MODULE TEST	29
6.2	INVERTER MODULE TEST	30
6.3	SEMITOP MODULE TEST	32
6.4	CABLE CONNECTIONS TEST (LINK FAIL)	33
<b>7</b>	<b>DESCRIPTION OF BOARDS</b>	<b>34</b>
7.1	INTERFACE BOARD (B0056)	34
7.2	DISPLAY CARD (B0057)	35
7.3	BATTERY CHARGER BOARD (B0060)	37
7.4	uC + DSP BOARD (B0067)	39
7.5	BATTERY CHARGER BOARD (B0084) (OPTIONAL)	40
7.6	PARALLEL BOARD (B0085)	41
7.7	AUXILIARY POWER SUPPLIES BOARD (B0102)	42
7.8	BOOST DRIVER BOARD (B0121)	44
7.9	CONTROL BOARD (B0122)	45
7.10	LEM BOOST BOARD (B0124)	46
7.11	INPUT BOARD (B0125)	47
7.12	OUTPUT BOARD (B0126)	49
7.13	24V RELAY BOARD (B0127)	51
7.14	CB 20A ADAPTOR BOARD (B0132) (OPTIONAL)	52
7.15	FILTER BOARD (B0133)	53
7.16	INVERTER DRIVER BOARD (B0135)	54
7.17	INVERTER BUS BARS BOARD (B0137) (NOTE: for SATURN60A and NOT SATURN60B)	55
7.18	PFC BUS BARS BOARD (B0138) (NOTE: for SATURN60A and NOT SATURN60B)	56
7.19	LEM INVERTER BOARD (B0144)	57
7.20	BATTERY CY CAPACITORS BOARD (B0155)	58
7.21	NEUTRAL CY CAPACITORS BOARD (B0156)	59
7.22	PFC/INV. BUS BARS BOARD (B0180)	60
7.23	CY CAPACITOR BOARD FOR INPUT, OUTPUT AND BYPASS PHASES (B0181)	61
7.24	NEUTRAL CY CAPACITORS BOARD (B0182)	62
7.25	PFC/INV. BUS BARS BOARD (B0183)	63

<b>8</b>	<b>SERVICE OPERATIONS ON THE UPS</b>	<b>64</b>
8.1	HOW TO OPEN THE UPS	64
8.2	REPLACING THE FANS	65
8.3	REPLACING THE INPUT FILTERSBOARD (B0133-01.)	68
8.4	REPLACING THE OUTPUT FILTERS BOARD (B0133-02.)	69
8.5	REPLACING THE HEATSINK TEMPERATURE SENSOR WIRING	69
<b>9</b>	<b>MAP OF MAIN READINGS</b>	<b>71</b>
9.1	INPUT VOLTAGES	71
9.2	BYPASS VOLTAGES	72
9.3	BATTERY VOLTAGES	73
9.4	INVERTER VOLTAGES	74
9.5	OUTPUT VOLTAGES	75
9.6	OUTPUT CURRENTS	75
<b>10</b>	<b>STATUS / ALARM CODES</b>	<b>76</b>
<b>11</b>	<b>TROUBLESHOOTING TABLES</b>	<b>77</b>
11.1	TROUBLESHOOTING 'FAULT' TYPE PROBLEMS	77
11.2	TROUBLESHOOTING 'LOCK' TYPE PROBLEMS	81
<b>12</b>	<b>APPENDIX</b>	<b>85</b>
12.1	LIST OF USEFUL DOCUMENTS	85
12.2	LIST OF BOARDS	85



## 2 SOFTWARE OPERATIONS

### 21 SAVING THE UPS LOG FILE

This should be performed before any operation is carried out on the UPS.

To save the log file use the GpDownload application provided with the UcomGp software. Please read the instructions for this application for the correct procedure to be followed.

#### IMPORTANT:

In the event you need to save log files for a UPS that is visibly damaged (i.e. displaying clear damage to the power boards and/or power modules), we recommend you follow the **safety procedure**

(in order to avoid the DC capacitor bank pre-loading stage).

**With the UPS fully switched off,**

#### for SINGLE INPUT UPS:

- Remove the fast-on connectors inserted into connector FN1 (Vin) from the B0125 boards for each phase (see Fig. 33 on page 47) and temporarily isolate the hanging fast-on connectors on wiring 0CBSU0040x.
- Close the SWIN and save the log file.

#### for DUAL INPUT UPS:

- Simply close the SWBYP and save the log file.

### 22 CONFIGURING THE UPS

To configure the UPS, use the dedicated UcomGp software. Please read the dedicated manual for this software for instructions about this application and the correct procedure to be followed.

### 23 UcomGp SOFTWARE

UComGP is a package of applications for the advanced analysis of log files and real-time diagnostics for UPS belonging to the Multi Sentry range (from 10kVA to 120 kVA).

Communication between PC and UPS, for the applications that require it, takes place via serial communication port RS232.

The package is currently comprised of seven different applications:

- GpDownload - Log Downloader
- GpHistory - Log Analyzer
- GpEvent - Event Analyzer
- GpRealTime - Status Analyzer
- GpDebug - UPS Debugger
- GpCalibrate - UPS Calibrator
- GpConfig - UPS Configuration tool

For further information on the applications listed above please see:

- f* UCOMGP Manual RM900
- f* UCOMGP Configuration tool Manual RM901

### 24 UPDATING THE FIRMWARE

In order to update the firmware, the dedicated "YMSTPRGA (MICRO & DSP PROGRAMMING KIT)" kit must be used to program the microprocessor and/or DSP. Please see the instructions for this application, attached to the kit.

**The firmware to be used is the following:**

Firmware	µProcessor	DSP
60-80-100kVA	FW022-xxxx	FW023-xxxx

## 3 SWITCHING THE UPS ON/OFF

See the instruction manual before carrying out any operations on the machine.

### 3.1 SWITCHING OFF THE UPS WHILST DELIVERING POWER TO THE LOAD

- 1) Close the SWMB
- 2) Set the UPS to stand-by using the display
- 3) Open the SWIN, SWBY (if present) and SWOUT
- 4) Wait for the display to shut down
- 5) Open the disconnection switch/fuses for the UPS external battery line

### 3.2 SWITCHING OFF THE UPS WHILST CUTTING OFF THE POWER SUPPLY TO THE LOAD

- 1) Set the UPS to stand-by using the display
- 2) Open the SWIN, SWBY (if present) and SWOUT
- 3) Wait for the display to shut down
- 4) Open the disconnection switch/fuses for the UPS external battery line

### 3.3 RESTARTING THE UPS

- 1) Close all battery fuses
- 2) Close the SWIN, SWBY (if present) and SWOUT
- 3) **IMPORTANT:** Switch the UPS on by entering and confirming SYSTEM ON using the display
- 4) If closed, open the SWMB

### 3.4 STARTING THE UPS FROM THE BATTERY

**Important:** this type of start-up should only be carried out if mains power is down and ONLY with the SWMB switch open. Start-up with the SWMB closed is only possible on UPS with a separate bypass option and where the bypass line is present.

**NOTE:** the minimum voltage for battery start-up is 236Vdc (11.8V for monoblock).

- 1) Close all battery fuses
- 2) Close the SWIN, SWBY (if present) and SWOUT
- 3) Press and hold down the "cold start" button
- 4) Switch the UPS on by entering and confirming SYSTEM ON


### 3.5 ADDITIONAL SERVICE OPERATIONS

Additional service operations are available using the dedicated UcomGp software. See the application manual for further details.

## 4 UPS INTERNAL STRUCTURE


For further details, see the instruction manual:

### 4.1 DISCONNECTION SWITCH POSITIONS



60 – 80K

Fig.1



100K

Fig.2

#### NOTE:

- the auxiliary contact on both SWOUT and SWMB disconnection switches is normally closed (NC) (with the disconnection switch open)
- the auxiliary contact on disconnection switch QN is normally open (NO) (with the disconnection switch open)

model K60**A**... model K80**A**...



model K60**B**... model K80**B**...



model M10**A**...



model M10**B**...



**Fig.3**



model K60**A**... model K80**A**... with separate  
BYPASS input



model K60**B**... model K80**B**... with separate  
BYPASS input



model M10**A**... with separate  
BYPASS input



model M10**B**... with separate  
BYPASS input




**Fig4**

## 42 BOARD /COMPONENT POSITIONS INSIDE THE UPS.

With reference to the following diagrams, there is:

- 1) BOOST DRIVER board (B0121)
- 2) BOOST LEM board (B0124)
- 3) INPUT board (B0125)
- 4) OUTPUT board (B0126)
- 5) INVERTER DRIVER board (B0135)
- 6) INVERTER BUS BARS board (B0137) (B0183 on SATURN60B...)
- 7) PFC BUS BARS board (B0138) (B0183 on SATURN60B...)
- 8) INVERTER LEM board (B0144)
- 9) AUX PS board (B0102)
- 10) 10A BATTERY CHARGER board (B0060)  
25A BATTERY CHARGER board (B0084)  
(OPTIONAL)
- 11) 24V RELAY board (B0127)
- 12) CONTROL board (B0122)
- 13) DSP+uC CONTROL board (B0067)
- 14) INTERFACE board (B0056)
- 15) INPUT FILTER board (and BYPASS line) (B0133)
- 16) OUTPUT FILTER board (B0133)
- 17) BATTERY CY CAPACITORS board (B0155)
- 18) CB 20A INTERFACE board (B0132) (OPTIONAL)
- 19) PARALLEL board (B0085) (OPTIONAL)
- 20) PHASES CY CAPACITORS board (B0181)
- 21) N CY CAPACITORS board (B0182)
- 22) INVERTER INDUCTOR
- 23) POSITIVE BOOST INDUCTOR
- 24) NEGATIVE BOOST INDUCTOR
- 25) INVERTER CAPACITOR (150uF 250VAC)
- 26) PFC+ CAPACITOR (50uF 250VAC)
- 27) PFC- CAPACITOR (50uF 250VAC)
- 28) ELT. POSITIVE CAPACITOR BANK
- 29) ELT. NEGATIVE CAPACITOR BANK
- 30) INPUT CAPACITORS (50uF 330VAC)
- 31) INPUT RELAY
- 32) OUTPUT RELAY (for 60-80kVA)
- 33) OUTPUT RELAY (for 100kVA)
- 40) AUX PS BOARD FAN (80x80, 24Vdc)
- 41) BATTERY CHARGER BOARD FAN (92x92, 12Vdc)
- 42) OUTPUT POWER HEATSINK FAN (120x120, 24Vdc)
- 43) INPUT POWER HEATSINK FAN (120x120, 24Vdc)








Fig.6






Fig.7







Fig.8





#### 43 UPS BLOCK DIAGRAM

## 44 SINGLE PHASE BLOCK DIAGRAM

The diagram below shows the basic layout of one phase with the main elements mounted on the boards.




Fig.13

Legend:

1) Input fuses	60 - 80kVA	160A FF240V
	100kVA	180A FF240V
2) Battery fuses	60 - 80kVA	80A F500V
	100kVA	100A F690V
3) Output fuses	60 - 80kVA	160A FF240V
	100kVA	180A FF240V


4) Input stage with rectifying diodes and battery SCR in Semitop module

5) Bypass SCR module

6) Input relay

7) Inverter output relay

## 45 SINGLE PHASE ELECTRICAL DIAGRAM



## 46 FAN POWER SUPPLY CONNECTION

The 24Vdc power supply voltage required for fan operation is generated by auxiliary power supplies board B0102. This power supply is sent to the 24V relay board (B0127) and is distributed from here to the individual fans for each power board. Please refer to the wiring shown in Fig. 14.




Fig14

### NOTE:

in the event of the failure of the 24Vdc power supplies from board B0102, with the UPS in BYPASS operating mode, B0127 supplies the output fans only.



## 5 AUXILIARY POWER SUPPLY FAILURE (L01)

### 5.1 TESTS

Board B0102 is supplied from 4 different power sources:

- phase 1 of the input mains power
- phase 2 of the input mains power or the bypass input mains power if the UPS is dual input (this power source is also used for the redundant power supply of the static bypass).
- direct current from the DC capacitor bank
- battery voltage for battery start

Board B0102 generates different voltages for supplying the different parts of the UPS. We can therefore distinguish between:

- $\pm 15V$  voltage (for the booster, battery charger, inverter LEM and battery charger fan).
- $\pm 12V$  voltage (analogue part of control board B0122)
- 24V voltage (for the fans, from a separate circuit that takes up current from the negative capacitor bank)
- 24V voltage (for the bypass fans and relay control, generated by board B0127)
- HF voltage (27V 50KHz) for the battery SCR (square wave)
- HF voltage (27V 50KHz) for the bypass SCR (square wave)
- HF voltage (27V 100KHz) for the isolated power supplies for the power stages (IGBT booster and inverter), for the power supply to the electronics of board RS232 (B0056) and for the battery charger board (B0060).

All auxiliary power lines ( $\pm 15V$ ,  $\pm 12V$  and HF 50KHz) first pass through the control board, and are distributed from here to the various parts of the UPS via flat connection cables.


The HF 100KHz power supply generated by the main power supply unit is distributed to the power boards via the control board (B0122). The battery charger receives the HF 100KHz signal directly from the main power supply unit.

Board RS232 receives this power supply via the following route:


main power supply unit (B0102) → control board (B0122) → micro DSP board (B0067).

In the diagrams below the dotted line represents the route of each single power supply.

## 52 15V - LEM POWER SUPPLY




## 53 12V POWER SUPPLY - ANALOGUE PART OF CONTROL BOARD






## 54 24V POWER SUPPLY FOR FANS (regulated)




## 55 24V EMERGENCY POWER SUPPLY FOR FANS (fault B0102)


**NOTE:** only the output dissipator fans are supplied.



## 56 HF 50KHz POWER SUPPLY FOR BATTERY AND BYPASS SCR



## 57 HF 100KHz POWER SUPPLY FOR POWER STAGES AND RS232




## 58 "AUX KO" (L01) DETECTION LOGIC

A logic test is carried out on the control board to check whether the auxiliary power supplies are present and correct. The test is performed:

- on +3V3, +12V, -12V voltages (for the analogue part of the control board);
- on HF+ 100KHz voltages drawn from Aux. power supplies board B0102.

If all the power supplies are correct, the UPS starts up; if the logic AND gives a negative result, the machine stops and displays L01.




The difficulty in resolving this kind of fault lies in identifying the cause of the problem. In particular it is necessary to understand why the control logic of board B0122 has failed (the failure is not necessarily due to an incorrect voltage supplied by the power supply).

## 59 CHECK AUX VOLTAGE (L01)


To understand the problem about the L01 alarm, is necessary to check the voltage/s not present. So, is possible to measure, on control board B00122, these points (with UPS in standby mode):

On connector J1  
on board  
B00122 between  
pins

- 1 & 23 → +12V
- 3 & 23 → -12V
- 4 & 23 → +3,3V
- 5 & 23 → +5V



## 5.10 MAIN POWER SUPPLY UNIT FAILURE




### OBSERVATIONS

If the auxiliary power supply unit ceases to provide the correct power supply (i.e. the 12V or HF supplies), the logic board stops the UPS and displays error L01.


In the most serious cases the machine may not switch on if the voltage supplied from the power supply unit is insufficient to activate the logic board.

The presence of power supply voltages can be checked directly at board B0102 by disconnecting connector J9 (**with the UPS completely switched off**) and leaving J11 connected. Close the SWIN and check for the presence of power supply voltages and, if possible, the presence of the HF+ supply (measuring between HF+ and N with the tester in DC mode the reading should be approx. 27V).

In the event of missing or incorrect power supplies, replace board B0102.




## 5.11 MICRO DSP / CONTROL BOARD FAILURE



It is possible that a fault at the logic boards, which affects an integrated circuit, may produce error L01 due to an error in the auxiliary power supplies test.



## 5.12 BOARD RS232 FAILURE



The failure of a component of board RS232 (supplied by a HF line directly through the control board and DSP micro board) could cause error L01. Often, in the event of the failure of this board, the UPS also signals that the EPO is disconnected, or that a remote command is present (in reality this is a false command generated by the fault).

A serious fault may also damage the power supply unit, which should, if necessary, be replaced after replacing board RS232.

## 5.13 FAN FAILURE

The presence of a blocked fan or a fan with a short circuit winding may damage fuse F1 on the main power supply unit board (B0102). After replacing the damaged fan, check and if necessary replace fuse F1.





## 62 INVERTER MODULE TEST

Based on the layout of Fig. 17 and pin layout of Fig. 18 use a multimeter to check the condition of the inverter modules. Specifically check that the diodes are neither open nor short circuited by measuring the direct bias voltage (valid for 60-A, 80 and 100 KVA).




Fig17






Fig18

In the event of damage detected following checks on the INVERTER module test, replace the module and associated driver board (included in the IGBT spare part kit).

For SATURN 60B, use the layout shown below



**Fig.19**

## 63 SEMITOP MODULE TEST

In the event of the failure of the PFC module and/or INVERTER, in addition to replacing the faulty components (IGBT modules, boards, etc.), the condition of the rectifier bridges on the other two phases should also be checked using a multimeter.

The component in question is the input stage with rectifier diodes and battery SCR in the Semitop module on board B0125 (2 modules on each board).

Specifically, use the layout and pin layout given below to check that the two SCR are not short-circuited between the anode and cathode and that the two diodes are neither open nor short circuited, measuring the direct bias voltage.





Fig20

If one of these components is faulty the affected input board must also be replaced.

## 64 CABLE CONNECTIONS TEST (LINK FAIL)

If necessary, use a multimeter set to ohmmeter mode to check the following on board B0122:

- resistance within the range of 0-15 between test points TP1 and TP6
- resistance within the range of 1-2k between test points TP6 and TP7

If the tests give a positive result it means that the flat cables have been connected correctly. If this is not the case, check the correct insertion of the flat cables into the respective holders on the CS.

### BOARD B0122, TEST POINT POSITIONS




Fig21

## 7 DESCRIPTION OF BOARDS

### 7.1 INTERFACE BOARD (B0056)

Versions:

B0056-02. Interface Card SATURN10-120

**NOTE :** on UPS without accessories JP3, JP4, JP6 must be closed and JP1, JP2 must be open.




Fig22

Connector	Description	Notes
J3	Flat connection from relay board	From aux relay slot
J6	EPO connector	
J8	Flat connection from DSP-uP board	From B0067
J9	Flat connection from DSP-uP board	From B0067 and slot1
J11	Connection to slot 2	To slot 2
FN1-FN2	Powershare connectors	


## 72 DISPLAY CARD (B0057)

Versions:

B0057-02. Display Card SATURN - Neutral Version

The display board is made up of the following main elements:

- 1) DL1, 2, 3, 4, 5 and 6 Led indicator
- 2) SW1, 2, 3, 4 Are selection buttons



Led	Description	Note
DL1	Mains operation LED	
DL2	Battery operation LED	
DL3	Load on bypass LED	
DL4	Standby/alarm LED	
DL5	Replace batteries LED	
DL6	ECO mode LED	




Fig24

RV2

Connector	Description	Note
J1	Flat connection to uC+DSP board	To B0067
RV2	Trimmer to regulate the contrast on display	

ATTENTION: It is important when starting the UPS in a very cold environment to allow the display time to warm up before adjusting the contrast via RV2.




## 73 BATTERY CHARGER BOARD (B0060)

Versions:

B0060-02. Battery Charger 10A Card SATURN 30-100 (for all sizes)

The battery charger board is made up of the following main elements:

- 1) 2 fuses 6.3X32 - 16A 500V rapid
- 2) DC Bus pre-charge resistors from battery (4 x 22 10W)
- 3) input capacitors
- 4) output capacitors
- 5) dual buck + heatsink temperature sensor
- 6) current sensors
- 7) buck inductances
- 8) blocking diodes






J2

Fig.25

Connector	Description	Notes
J1	Battery charger input connector	
J2	Flat connection from control board	From B0122
J3	Fan power supply connector +12Vdc*	
J7	Battery charger output connector	



## Connector pin layout:



## 74 uC + DSP BOARD (B0067)

Version:

B0067-01. DSP+uC Control Card for SATURN 60-100




Fig26

Connector	Description	Notes
J3	Flat connections to interface boards for SLOT 1	To B0056 and SLOT 1
J4	Flat connections to display boards	From B0057
J5	Connector uC to control board	To B0122
J6	Connector uC to parallel board	
J7	Connector DSP to control board	To B0122
J8	Flat connections to interface boards for SLOT 2	To B0056 and SLOT 2

Test point	Voltage present
Between TP11 and TP12	+5V
Between TP7 and TP8	+1,9V
Between TP9 and TP10	+3,3V
Between TP14 and TP10	+2,3V
Between TP5 and TP6	+3,3V
Between TP13 and TP10	+4,6V

Led turns on	Means
DL1	+5V present
DL2	Reset uC
DL3	+1,9V present

## 75 BATTERY CHARGER BOARD (B0084) (OPTIONAL)

Versions:

B0084-01. Battery Charger 25A Card SATURN 100-120

NOTE: See manual 0NMMASTER3... (for option YMSTER3A 480V 20A 60-100kVA)

The battery charger board is made up of the following main elements:

- 1) 2 output fuses 10mmX38 - 32 A 500V
- 2) 2 input fuses 6.3mmX32 - 25A 500V
- 3) preload resistors from battery (6 x 22 10W)
- 4) input capacitors
- 5) Battery Charger output diodes
- 6) positive buck + heatsink temperature sensor
- 7) negative buck + heatsink temperature sensor
- 8) output capacitors
- 9) current sensors
- 10) buck inductances




Fig27

Connector	Description	Notes
J5	Battery charger input connector	
J6	Flat connection from control board	From B0122
J9	Fan power supply connector	
J10	Battery charger output connector	

## 76 PARALLEL BOARD (B0085)

Version:

B0085-01. Parallel Card SATURN (for all sizes)

The parallel board is made of these elements:

- 1) SW1 to select the "Start" or "Continue" mode
- 2) Yellow led indicates that SW1 is in "Start" position  
Green led indicates that the parallel board is powered
- 3) SW2 to select the terminating resistor
- 4) SW3 the input communication line is opened or closed
- 5) SW4 the output communication line is opened or closed




Fig28

Connector	Description	Note
J1	Flat connection to uC+DSP board	To B0067
J2	Connection to auxiliary board	To B0102
J4	Output communication line RJ45- OUT	To B0085
J5	Input communication line RJ45- IN	To B0085



## 77 AUXILIARY POWER SUPPLIES BOARD (B0102)

Versions:

B0102-02. Aux power supply card SATURN 60-100 (for all sizes)

The auxiliary power supplies board is made up of the following main elements:

- 1) fuse 6.3x32 - 2A 500V GF (F2)
- 2) DC Bus pre-charge from mains
- 3) power supply unit +27, +15, +12\_relay, -18V
- 4) fan power supply unit
- 5) redundant bypass power supply unit
- 6) Fan power supply unit output fuse 8A 250V 5X20 delayed (F1)




Fig29

Connector	Description	Notes
J1	Vbat connector for battery start-up	
J4	Connector for 1/0	Put jumper
J8	Flat connector from control board	From B0122
J9	Connector for power supplies to control board	to B0122







Connector	Description	Notes
J10	Fan power supply connector	
J11	DC BUS, HF connector	
J12	Connector for 1/0	
J13	HF connector	
J15	Connector for mains power supply	pin1 Æ from C_IN (PH1) pin2 Æ from C_IN (PH2) (with single input UPS) pin2 Æ from PH2 SWBYP (with dual input UPS)
FN6	+batt connector for battery start-up	

LEDs	Description	Notes
DL1	Aux power good LED	

Connector pin layout:



Power supply diagram:



## 78 BOOST DRIVER BOARD (B0121)

Versions:

B0121-01. Boost driver Card SATURN 60-80-100

The layout of the boost driver board connectors is given below.




Fig30

Connector	Description	Notes
J1	Temperature sensor connection	
J2	Connection towards boost module	
J3	Flat connection from input board	From B0125



## 7.10 LEM BOOST BOARD (B0124)

Versions:

B0124-01. LEM Boost Card SATURN 80-100

B0124-02. LEM Boost Card SATURN 60

J1







Fig.32

Connettore	Descrizione	Note
J1	Connections to input board	To B0125

Connector	Description	Notes
J1	Flat connection from control board	From B0122
J3	Flat connection from boost driver board	From B0121
J4	Connection to boost LEM board	From B0124
FN1	Connection to input capacitors	
FN2	Connection to neutral bar	
F_IN	Input phase terminal	

BATT+/BATT- +batt. / -batt. terminals

PZ1/PZ2 Terminals to capacitors PFC- /PFC+



9 10 11

15 16



## 7.12 OUTPUT BOARD (B0126)

Versions:

B0126-01. Output Card SATURN 60-80

B0126-02. Output Card SATURN 100

The output board is made up of the following main elements:

- 1) Output fuse.
- 2) BYPASS SCR module
- 3) UPS output current TA
- 4) Bypass current TA (feedback protection)




Fig34

Connector	Description	Notes
J2	Flat connection from inverter driver board	From B0135
J4	Connection towards Bypass SCR	
J5	Connection from inverter LEM board	From B0144
J6	Flat connection from control board	From B0122
FN1	Connection to neutral bar	
F1_inv	Terminal for cable from inverter filter capacitor	
F1_out	Terminal for cable from output relay (Tx)	
PZ1	Terminal for cable from SWBYP disconnection switch	

Connector	Description	Notes
PZ2	Terminal for cable from SWOUT disconnection switch	
PZ3	Terminal for cable from output relay (Lx)	

## 7.13 24V RELAY BOARD (B0127)


Versions:

B0127-01. 24V contactors Card SATURN 60-80

B0127-02. 24V contactors Card SATURN 100

The relay board is made up of the following main elements:

- 1) Input fuse.
- 2) Power supply unit.
- 3) Relay control.



J9

Fig35

Connector	Description	Notes
J2	Connector DC, PH1, PH2	
J5	Connection towards input relay coil	
J6	Connection towards output relay coil	
J7	Fan connection, power supplies board,	From B0102
J8	Connection towards neutral bar	
J9	Flat connection from control board	From B0122

## 7.14 CB 20A ADAPTOR BOARD (B0132) (OPTIONAL)

Versions:

B0132-01. Adapter CB 20A card SATURN 60-100 (for all sizes)

The layout of the board connectors is given below




Fig36

Connector	Description	Notes
J1	Flat connection from control board	From B0122
J2	Flat connection from board CB 20A	From B0084
J5	Connection towards power supplies board (HF)	From B0102

## 7.15 FILTER BOARD (B0133)


Versions:

B0133-03. Replaced by B0133-01. Filter Input Card SATURN 60-100

B0133-02. Filter Output Card SATURN 60-100 (replaced by B0133-04.)

B0133-04. Filter Output Card SATURN 60-100

The layout of the board connectors is given below



J1

Fig37

Connector	Description	Notes
J1	Connector PH1, PH2, PH3, N input or output	
PZ1	Connection towards GND (fastening turret)	
PZ2	Connection towards GND (fastening turret)	
PZ3	Connection towards GND (fastening turret)	
PZ4	Connection towards GND (fastening turret)	





## 7.16 INVERTER DRIVER BOARD (B0135)

Versions:

B0135-01. Driver Inverter Card SATURN 60-100

B0135-02. Driver Inverter Card SATURN 60B

The layout of the inverter driver board connectors is given below.




Fig38

Connector	Description	Notes
J1	Flat connection from control board	From B0126
J2	Connection to inverter module	
J3	Temperature sensor connection	

## 7.17 INVERTER BUS BARS BOARD (B0137) (NOTE: for SATURN60A and NOT SATURN60B)

Versions:

B0137-01. inverter Card SATURN 60-80

B0137-02. inverter Card SATURN 100

The inverter power board is made up of the following main elements:

- 1) Inverter module
- 2) Electrolytic positive capacitor bank
- 3) Electrolytic negative capacitor bank




Fig39

Connector	Description	Notes
J1	Connection from input board (phase 2 only)	From B0125
PZ4	Inverter coil cable terminal	

## 7.18 PFC BUS BARS BOARD (B0138) (NOTE: for SATURN60A and NOT SATURN60B)

Versions:

B0138-01. PFC Card SATURN 60-80-100

The PFC power board is made up of the following main elements:

- 1) BOOST module
- 2) Electrolytic positive capacitor bank
- 3) Electrolytic negative capacitor bank




Fig40

Connector	Description	Notes
PZ4	Boost coil cable terminal UP	
PZ5	Boost coil cable terminal DW	

## 7.19 LEM INVERTER BOARD (B0144)

Versions:

B0144-01. LEM inverter Card 80-100

B0144-02. LEM inverter Card 60

The PFC power board is made up of the following main elements:

- 1) Current transducer
- 2) Power supply connector and output current measure




Fig41

Connector	Description	Notes
J1	Connection to output board	A B0126

## 7.20 BATTERY CY CAPACITORS BOARD (B0155)

Versions:

B0155-02. BATTERY CY Capacitor Card SATURN  
100

B0155-03. BATTERY CY Capacitor Card SATURN 60B-  
80B

B0155-04. BATTERY CY Capacitor Card SATURN  
100B

The layout of the board connectors is given below.




Fig42

Connector	Description	Notes
PZ1	Not used.	
PZ2	Connection to BATTERY POSITIVE	
PZ3	Connection to BATTERY NEGATIVE	
PZ4	Connection to GND (fastening stud)	
PZ5	Connection to GND (fastening stud)	

## 7.21 NEUTRAL CY CAPACITORS BOARD (B0156)

Versions:

B0156-01. N CY Capacitor Card SATURN 100

The layout of the board connectors is given below.




Fig43

Connector	Description	Notes
PZ1	Connection to N (QN)	
PZ2	Connection to N (QN)	
PZ3	Connection to N (QN)	
PZ4	Connection to GND (fastening stud)	
PZ5	Connection to GND (fastening stud)	



## 7.22 PFC/INV. BUS BARS BOARD (B0180)

Versions:

B0180-01. Capacitor Elect. x4 Card SATURN60 B

NOTE : the following configurations of electrolytic capacitors can be installed:

- 2+2 3300uF - 1+1  
6800uF

The inverter power board is made up of the following main elements:

- 1) Inverter module
- 2) Electrolytic positive capacitor bank
- 3) Electrolytic negative capacitor bank
- 4) BOOST module




Fig44

Connector	Description	Notes
J1	Connection from input board (phase 2 only)	From B0125
PZ4	Boost coil cable terminal UP	
PZ5	Boost coil cable terminal DW	

## 7.23 CY CAPACITOR BOARD FOR INPUT, OUTPUT AND BYPASS PHASES (B0181)

Versions:

B0181-01. Filter Card CY IN/OUT/BY SATURN 60-100

The layout of the board connectors is given below.




Fig45

Connector	Description	Notes
PZ1	Connection to PH3	
PZ2	Connection to PH2	
PZ3	Connection to PH1	
PZ4	Connection to GND (fastening screw)	
PZ5	Connection to GND (fastening screw)	
PZ6	Connection to GND (fastening screw)	

## 7.24 NEUTRAL CY CAPACITORS BOARD (B0182)

Versions:

B0182-01. N CY Capacitor card 60B-80B-100B

The layout of the board connectors is given below.




Fig46

Connector	Description	Notes
J1	Connection to N (fastening screw)	
J2	Contact to GND	
J3	Connection to N (fastening screw)	
J4	Contact to GND	

## 7.25 PFC/INV. BUS BARS BOARD (B0183)

Versions:

B0183-01. Capacitor Elect. x2 Card SATURN60 B

NOTE : only the configuration with electrolytic capacitors may be installed:

- 1+1 6800uF

The inverter power board is made up of the following main elements:

- 1) Inverter module
- 2) Electrolytic positive capacitor bank
- 3) Electrolytic negative capacitor bank
- 4) BOOST module




Fig47

Connector	Description	Notes
J1	Connection from input board (phase 2 only)	From B0125
PZ4	Boost coil cable terminal UP	
PZ5	Boost coil cable terminal DW	

## 8 SERVICE OPERATIONS ON THE UPS

### 8.1 HOW TO OPEN THE UPS

To access the terminal area, first ensure the UPS is completely isolated from the mains and battery sources. Remove the lower front panel by removing all the screws.

To access the internal boards, remove the wrap-around covers by removing screws 1; see Fig. 48. Half unscrew screws 2. Then unscrew the remaining screws and release the wrap-around cover. If necessary, repeat the operation for the opposite wrap-around side cover.

To remove the top cover unscrew screws 3; see Fig. 48 .




Fig48

## 82 REPLACING THE FANS

This operation can only be performed with the machine switched off, with the input/output disconnection switches open and the battery disconnected.


1) remove the ducts from the heatsinks:

a) remove the fastening screws

PFC/inverter heatsinks: n°2 screws per duct

battery charger board: n°3 screws per duct


refer to the diagrams below for screw positions




**Fig49**



- b) remove the ducts, taking care not to damage the fastening tabs
- 2) disconnect the fans, removing the red and black cables from the terminals
- 3) remove the protection grilles and free the fans, referring to Fig. 50 and
- 4) Fig. 51 for the positions of fastening screws



**Fig50**



**Fig51**

To fit the new fans follow the instructions for removal in reverse.

## 83 REPLACING THE INPUT FILTERSBOARD (B0133-01.)

It may be necessary to replace the filters board if it has been damaged by the VDR blowing, or due to the deterioration of a component. Proceed as follows to replace the filters board:

- 1) Open all disconnecting switches. **IMPORTANT:** it is very important that the batteries are disconnected.
- 2) **IMPORTANT:** completely disconnect the UPS from any power supply, including any battery boxes, other UPS in parallel or other power sources. Make sure there is no voltage present in the board.
- 3) Detach the hanging cable connection
- 4) Remove the fastening screws from the board
- 5) Replace the board. **IMPORTANT:** the new INPUT FILTERS board must have code B0133-01 (SATURN 60-80) or B0133-03 (SATURN 100);  
(**DO NOT use board B0133-04. (or B0133-02.)**; See Fig. 52.
- 6) Secure the board to the casing by tightening the fastening screws




Fig.52

## 84 REPLACING THE OUTPUT FILTERS BOARD (B0133-02.)

It may be necessary to replace the filters board if it has been damaged by the VDR blowing, or due to the deterioration of a component. Proceed as follows to replace the filters board:

- 1) Open all disconnecting switches. **IMPORTANT:** it is very important that the batteries are disconnected.
- 2) **IMPORTANT:** completely disconnect the UPS from any power supply, including any battery boxes, other UPS in parallel or other power sources. Make sure there is no voltage present in the board.
- 3) Detach the hanging cable connection
- 4) Remove the fastening screws from the board
- 5) Replace the board. **IMPORTANT:** the new OUPUT FILTERS board must have code B0133-04. (or B0133-02.);  
(**DO NOT use board B0133-01.** (or B0133-03.)); See Fig. 52.
- 6) Secure the board to the casing by tightening the fastening screws

## 85 REPLACING THE HEATSINK TEMPERATURE SENSOR WIRING

Each power assembly requires n°2 sensors with code 0CBCU0535: one for the Boost module and one for the Inverter module.

### REPLACING THE BOOST MODULE PTC:

- 1) Remove the MiniFit connector for the faulty sensor from connector J1 on board B0121.
- 2) Remove the PTC from the BOOST heatsink (inserted into hole A; see Fig. 53).
- 3) Insert the MiniFit connector for the new wiring into connector J1 on board B0121.
- 4) Fill hole B (see Fig. 53) on the BOOST heatsink with Dowcorning 744RTV SEALANT

WHITE silicon and slide the end of the wiring with the temperature sensor in as far as it will go. Note: use only the specified sealant.

- 5) Let the adhesive dry, keeping the sensor in position.




Fig53

#### REPLACING THE INVERTER MODULE PTC:

- 1) Remove the MiniFit connector for the faulty sensor from connector J3 on board B0135.
- 2) Remove the PTC from the INVERTER heatsink (inserted into hole A; see Fig. 54).
- 3) Insert the MiniFit connector for the new wiring into connector J3 on board B0135.
- 4) Fill hole B (see Fig. 54) on the INVERTER heatsink with Dowcorning 744RTV SEALANT

WHITE silicon and slide the end of the wiring with the temperature sensor in as far as it will go. Note: use only the specified sealant.

- 5) Let the adhesive dry, keeping the sensor in position.





Fig54

## 9 MAP OF MAIN READINGS

The following section provides useful indications for troubleshooting problems with the UPS.

### 9.1 INPUT VOLTAGES



Input voltages are measured both by the  $\mu$ C and DSP; the measurement points are however different: the  $\mu$ C measures the voltage upstream of the input fuse and input contact, whilst the DSP measures it downstream from them.

The VIN\_uP reading on the display is shown as PH-N whilst the VIN\_DSP reading on the display is shown as PH-PH (this is only visible with the input relay closed, during start-up the reading is therefore only available at the end of the pre-loading stage).

With the machine switched off, use a multimeter to check that the input fuse on board B0125 is intact.

With the machine still off, check that there is no short circuit between the input relay contacts.

Test to check the continuity of the  $\mu$ C signal (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

		Phase 1	Phase 2	Phase 3	Notes
TL_IN		T1	T2	T3	
>	B0125	FN1	FN1	FN1	
	B0125	R1	R1	R1	150 kR
	B0125	R2	R2	R2	150 kR
	B0125	J1-15	J1-15	J1-15	
Flat Cable					
>	B0122	J17-15	J15-15	J11-15	
	B0122	R597	R557	R256	1.37 kR

(Position the probes between the two points marked with ">" to test the continuity of the flat cables)

Test to check the continuity of the DSP signal (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

		Phase 1	Phase 2	Phase 3	Notes
Fuse F2		After	After	After	
>	B0125	F2 (side Q3,Q4)	F2 (side Q3,Q4)	F2 (side Q3,Q4)	
	B0125	R3	R3	R3	150 kR
	B0125	R4	R4	R4	150 kR
	B0125	J1-16	J1-16	J1-16	
Flat Cable					
>	B0122	J17-16	J15-16	J11-16	
	B0122	R745	R743	R747	887 R

(Position the probes between the two points marked with ">" to test the continuity of the flat cables)



## 92 BYPASS VOLTAGES

Bypass voltage readings are measured by the  $\mu\text{C}$  only. The reading point is exactly next to PZ1 on board B0126 (output board).

To check for the presence of voltage, with the UPS switched on, measure between neutral and PZ1 on board B0126.

This reading is needed to synchronise the inverter and to enable or disable the bypass.

Test to check the continuity of the  $\mu\text{C}$  signal (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

		Phase 1	Phase 2	Phase 3	Notes
	Fuse	Before	Before	Before	
>	<u>B0126</u>	<u>PZ1</u>	<u>PZ1</u>	<u>PZ1</u>	
	<u>B0126</u>	<u>R21</u>	<u>R21</u>	<u>R21</u>	<u>150 kR</u>
	<u>B0126</u>	<u>R20</u>	<u>R20</u>	<u>R20</u>	<u>150 kR</u>
	<u>B0126</u>	<u>J6-18</u>	<u>J6-18</u>	<u>J6-18</u>	
	<u>Flat Cable</u>				
>	<u>B0122</u>	<u>J18-18</u>	<u>J16-18</u>	<u>J12-18</u>	
	<u>B0122</u>	<u>R199</u>	<u>R558</u>	<u>R257</u>	—

(Position the probes between the two points marked with "->" to test the continuity of the flat cables)

## 93 BATTERY VOLTAGES

The battery voltage readings, measured by the  $\mu$ C and the DSP, are taken at the output of board B0060 (battery charger board);

The reading shown on the display is that taken by the  $\mu$ C; this reading is used for regulating the battery charger, the batteries present test, the battery charge status and the "battery over voltage" alarm.

The reading taken by the DSP is only used for internal regulation.

Test to check the continuity of the  $\mu$ C signal (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

		DC +	DC -	Notes
>	B0060	J7-1	J7-3	
	B0060	R29	R27	2 MR
	B0060	R30	R28	2 MR
	B0060	J2-5	J2-6	
	Flat Cable			
>	B0122	J8-5	J8-6	
	B0122	R706	R674	57.6 kR

(Position the probes between the two points marked with ">" to test the continuity of the flat cables)

Test to check the continuity of the DSP signal (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

		DC +	DC -	Notes
>	B0060	J7-1	J7-3	
	B0060	R23	R26	2 MR
	B0060	R5	R4	2 MR
	B0060	J2-7	J2-8	
	Flat Cable			
>	B0122	J8-7	J8-8	
	B0122	R711	R760	40.2 kR

(Position the probes between the two points marked with ">" to test the continuity of the flat cables)

## 94 INVERTER VOLTAGES

The inverter voltage readings are taken by the DSP. The reading point is exactly next to fuse F1 (C\_INV side) on board B0126 (output board).

This reading is used to check the inverter and check the status of the out relay and inverter fuses (combined with the output voltage reading).

To check for the presence of voltage, with the UPS switched on, place the probes between neutral and the head of the fuse (C\_INV side).

Test to check signal continuity (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

	<u>Phase 1</u>	<u>Phase 2</u>	<u>Phase 3</u>	Notes	
>	<u>B0126</u>	<u>F1 (C INV side)</u>	<u>F1 (C INV side)</u>	<u>F1 (C INV side)</u>	<u>fuses</u>
	B0126	<u>R9</u>	<u>R9</u>	<u>R9</u>	<u>150 kR</u>
	B0126	<u>R8</u>	<u>R8</u>	<u>R8</u>	<u>100 kR</u>
	B0126	<u>J6-37</u>	<u>J6-37</u>	<u>J6-37</u>	
	Flat Cable				
>	B0122	J18-37	J16-37	J12-37	
	B0122	R699	R638	R330	49.9 kR

(Position the probes between the two points marked with ">" to test the continuity of the flat cables)

## 95 OUTPUT VOLTAGES

The output voltage readings are taken by the DSP only. The reading point is exactly next to PZ2 or PZ3 on board B0126 (output board). This reading is used to calculate the output power (combined with the I<sub>out</sub> reading) and to check the status of the out relay and inverter fuses (combined with the inverter voltage reading).

To check for the presence of voltage, with the UPS switched on, measure between neutral and slots PZ2 or PZ3.

Test to check signal continuity (this test should be carried out with the UPS switched off, not supplied and with the battery disconnected); with a multimeter set to ohmmeter mode, check the continuity between the following points:

	Phase 1	Phase 2	Phase 3	Notes
	<u>B0126</u>	<u>PZ2-PZ3</u>	<u>PZ2-PZ3</u>	<u>PZ2-PZ3</u>
	B0126	R15	R15	R15
>	B0126	R14	R14	R14
	B0126	J6-38	J6-38	J6-38
	Flat Cable			
	B0122	J18-38	J16-38	J12-38
>	B0122	R757	R753	R755
				301 KR

(Position the probes between the two points marked with ">" to test the continuity of the flat cables)

## 96 OUTPUT CURRENTS

The output current readings are taken by the DSP only. The reading is taken by the TA at the output of each single phase on board B0126 (output board). The TA reads the output current, i.e. that distributed by the inverter with the UPS on line or that distributed by the bypass with UPS in bypass mode. The TA is situated on the cables that connect B0126 to the SWOUT.

This reading is used to calculate the output power (combined with the V<sub>out</sub> reading).

---

## **10 STATUS / ALARM CODES**

For information on the meanings of status/alarm codes refer to the document:  
code RM021 Rev.-XX "STATUS/ALARM CODES".

## 11 TROUBLESHOOTING TABLES

The UPS is able to check and display its status and any faults and/or failures that may occur during operation on the display panel. In the event of a problem, the UPS reports the event by displaying the type of alarm and alarm code on the display panel.

### 11.1 TROUBLESHOOTING 'FAULT' TYPE PROBLEMS

The tables below provide useful information for troubleshooting problems connected with 'fault' type alarm codes. The table does not cover all possible UPS failure causes, the information contained here should be considered as a suggestion of the possible causes of problems and how they might be resolved.

Alarm code	Description	Possible cause	Boards affected	Corrective actions
F01	Internal communication error	Programming board inserted into communication slots	B0096	Remove the programming board from the slot
		Communications interface board faulty.	B0056	Replace board B0056
		Board B0067 faulty	B0067	Replace board B0067
F02	Incorrect cyclic direction of phases	Input phases connection error		Check input phases connection
F03	Input fuse blown phase 1	input diodes blown	B0125	Check for blown diodes and fuses. If necessary replace board B0125
F04	Input fuse blown phase 2			
F05	Input fuse blown phase 3			
F06	Phase 1 relay contact does not open	Input relay contacts blocked		Check relay. If necessary also check board B0127
F07	Phase 2 relay contact does not open			
F08	Phase 3 relay contact does not open			
F09	Positive branch capacitor preload failed	Short circuit in inverter and/or PFC stages	B0137 B0138	Replace the affected boards
		Control logic faulty	B0067 B0122	
F10	Negative branch capacitor preload failed	Input relay out of tolerance values		Check that $V_{in} < 250V$



F11	Boost stage fault	PFC stage short circuit	B0125 B0138	Replace the affected boards
		Control logic faulty	B0067 B0122	
F12	Incorrect cyclic direction of bypass phases	Connection error in bypass power supply		Check bypass power supply connection
F14	Sinusoid Phase 1 inverter distorted	Inverter stage short circuit	B0137	Replace the affected boards
F15	Sinusoid Phase 2 inverter distorted	Control logic faulty	B0067 B0122	
F16	Sinusoid Phase 3 inverter distorted	Phase-Phase short circuit		Check for SC between phases
F17	Inverter stage faulty	<u>Inverter stage blown</u> Control logic faulty	<u>B0137</u> B0067 <u>B0122</u>	Replace the affected boards
F19	Positive battery overvoltage	Batteries disconnected		UPS operation with the batteries disconnected may lead to an overvoltage at the battery charger output. Shut down and restart the UPS and reconnect the batteries. If the UPS is set up for operation without batteries (freq. conv) the CB is automatically disabled
F20	Negative battery overvoltage			
F23	Overload at output	Excessive load		Reduce the load
		Wrong UPS size following control board replacement		Set the correct size
		Output power reading faulty	B0126 B0067 B0122	Replace the affected boards
		Error in output voltage setting		Set the correct output voltage

F26	Phase 1 output relay blocked (does not open)	Failure in relay control circuit	B0067 B0122 B0127	Replace the affected boards
F27	Phase 1 output relay blocked (does not open)			
F28	Phase 1 output relay blocked (does not open)	Relay with damaged contacts		Replace the relay
F29	Phase 1 output fuse blown or output relay blocked (does not close)	Failure in relay control circuit	B0067 B0122 B0127	Replace the affected boards
F30	Phase 1 output fuse blown or output relay blocked (does not close)	Output fuse blown	B0126	Replace blown output fuse
F31	Phase 1 output fuse blown or output relay blocked (does not close)	Relay with damaged contacts		Replace the relay
F32	Battery charger stage faulty	Output voltage from CB is missing in one of the <u>two battery branches</u>	B0060	Check the flat cable connections and if necessary replace the affected boards
		CB control and feedback signals faulty	B0060 B0067 B0122	
F34	heatsink overheated	Cooling fans faulty	B0102	<ul style="list-style-type: none"> <li>• Check for SC at fans Æ replace fans</li> <li>• Check R194 on board B0102,</li> <li>• check voltage at connector J10, check fan power supply link Æ replace board B0102</li> </ul>
		Temperature readings faulty	B0067 B0122	Check the interconnections between the affected boards, if necessary replace the <u>boards</u>
		Temperature sensor faulty		Check temperature sensors

F37	Battery charger overheated	CB cooling fan faulty	B0060	<ul style="list-style-type: none"> <li>Check that the fitted fan is correct (12V) Æ replace fan</li> <li>Check for SC at the fan Æ replace fan</li> <li>Check voltage at connector Fx Æ replace board B0060</li> </ul>
		Incorrect duct installation	B0060	Check that the duct secured to board B0060 is correctly <u>installed</u>
		Temperature readings faulty	B0060 B0067 B0122	Check the interconnections between the affected boards, if necessary replace the <u>boards</u>
		Temperature sensor faulty	B0060	replace board B0060
F42	BOOST 1 battery fuses blown	Battery SCR blown	B0125	Check battery SCR (semitop)
F43	BOOST 2 battery fuses blown			
F44	BOOST 3 battery fuses blown			

## 11.2 TROUBLESHOOTING 'LOCK' TYPE PROBLEMS

The tables below provide useful information for troubleshooting problems connected with 'lock' type alarm codes. The table does not cover all possible UPS failure causes, the information contained here should be considered as a suggestion of the possible causes of problems and how they might be resolved.

Code	Description	Possible cause	Boards affected	Corrective action
L01	Incorrect auxiliary power supply	Aux power supplies missing B0102	B0102	Check that LED DL1 is lit on B0102 Æ if it is not lit check connections and/or replace board.
L02	One or more internal cables disconnected	Flat cables not connected or partially connected	All boards with flat cables	Check the connections of the UPS flat cables
L03	Phase 1 input fuse blown	input diode blown	B0125 B0138	Check if diode is blown Æ replace the fuse. Check Boost module
L04	Phase 2 input fuse blown			
L05	Phase 3 input fuse <u>blown</u>			
L06	Overvoltage at positive BOOST stage	Any unidirectional loads connected at <u>output</u>		Check for the presence of unidirectional loads at the output
L07	Overvoltage at negative BOOST stage	Output short circuit		Check for the presence of short <u>circuits at the output</u>
		Inverter stage short <u>circuit</u>		Check inverter stage
L08	Undervoltage at positive BOOST stage	The UPS does not have battery operation	B0125	Check the battery boost fuses and <u>battery SCR</u>
		Control logic faulty	B0067 <u>B0122</u>	Check the connections between the boards and if necessary replace them
		No mains power with the batteries disconnected		Check the battery box connection <u>and/or battery box fuses</u>
L09	Undervoltage at negative BOOST stage	Boost stage blown	B0138	Check PFC module and if necessary replace it
		Inverter stage <u>blown</u>	B0137	Check inverter module and if <u>necessary replace it</u>
L10	Static bypass switch faulty	Bypass SCR blown	B0126	Check bypass SCR and if necessary replace it

L11	Bypass output blocked L1			
L12	Bypass output blocked L2			
L13	Bypass output blocked L3			
L14	Overvoltage at phase 1 inverter	Inverter output capacitor faulty		Check the inverter output capacitor and if necessary replace it
L15	Overvoltage at phase 2 inverter			
L16	Overvoltage at phase 3 inverter	Inverter operating logic faulty	B0067 B0122	Replace the affected boards
L17	Undervoltage at Phase 1 inverter	Phase-Phase short circuit		Check for SC between the output phases
L18	Undervoltage at Phase 2 inverter			
L19	Undervoltage at Phase 3 inverter	Control logic faulty	B0067 B0122	Check the connections between the boards and/or replace the specified boards
L20	DC voltage at inverter output or Phase 1 inverter sinusoid distorted	Inverter blown	B0137	Check the inverter module for blown components Æ replace module if necessary
L21	DC voltage at inverter output or Phase 2 inverter sinusoid distorted	Control logic faulty	B0067 B0122	Check the connections between the boards and/or replace the specified boards
L22	DC voltage at inverter output or Phase 3 inverter sinusoid distorted	Phase-Phase short circuit		Check for the presence of SC at the output
L23	Overload at Phase 1 output	Excessive load		Reduce the load
L24	Overload at Phase 2 output	Wrong UPS size following control board replacement		Set the correct size
		Output power reading faulty	B0067 B0122 B0126	Replace the affected boards
L25	Overload at Phase 3 output	Error in output voltage setting		Set the correct output voltage

L26	Short circuit at Phase 1 output			
L27	Short circuit at Phase 2 output	Short circuit at neutral phase output		Check for the presence of SC between the phases and neutral at the output
L28	Short circuit at Phase 3 output			
L34	Phase 1 heatsink overheated	Cooling fans faulty	B0102	<ul style="list-style-type: none"> <li>Check for SC at fans <math>\text{Æ}</math> replace fans</li> <li>Check R194 on board B0102, check voltage at connector J10, check fan power supply link <math>\text{Æ}</math> <u>replace board B0102</u></li> </ul>
L35	Phase 2 heatsink overheated	Temperature readings faulty	B0060 B0067 B0122	Check the interconnections between the affected boards, if necessary replace the boards.
L36	Phase 3 heatsink overheated	Temperature sensor faulty		Check temperature sensors and replace them if necessary; see page69
L37	Battery charger overheated	CB cooling fan faulty	B0060	<ul style="list-style-type: none"> <li>Check that the fitted fan is correct (12V) <math>\text{Æ}</math> replace fan</li> <li>Check for SC at the fan <math>\text{Æ}</math> replace fan</li> <li>Check voltage at connector J3 <math>\text{Æ}</math> replace board B0060</li> </ul>
		Incorrect duct installation	B0060	Check that the duct secured to board B0060 is correctly installed
		Temperature readings faulty	B0060 B0067 B0122	Check the interconnections between the affected boards, if necessary replace the boards
		Temperature sensor faulty	B0060	Replace board B060



L38	Phase 1 heatsink temperature sensor faulty	Temperature readings faulty	B0067 B0122	Check the interconnections between the affected boards, if necessary replace the boards
L39	Phase 2 heatsink temperature sensor faulty	Temperature sensor faulty		Check temperature sensors
L40	Phase heatsink temperature sensor faulty			
L41	Battery charger temperature sensor faulty	Temperature readings faulty	B0060 B0067 B0122	Check the interconnections between the affected boards, if necessary replace the boards
		Temperature sensor faulty	B0060	Replace board B060
L42	BOOST 1 battery fuses blown	Battery SCR blown	B0125	Check battery SCR (semitop)
L43	BOOST 2 battery fuses blown			
L44	BOOST 3 battery fuses blown			

## 12 APPENDIX

### 12.1 LIST OF USEFUL DOCUMENTS

- Programming manual 0MNU073NP... (UPS PROGRAMMING KIT)
- Alarm code manual SATURN RM021 Rev..-
- XX
- UcomGp instruction manual RM900 Rev..
- UcomGp Configurator RM901 Rev..

### 12.2 LIST OF BOARDS

<u>board</u>	<u>description</u>	<u>quantity for ups</u>
B0056	Interface Card	1
B0057	Display Card	1
B0060	Battery Charger 10A Card	1
B0067	DSP+ $\mu$ C Control Card	1
B0084	Battery Charger 25A Card	1
B0085	Parallel Card	1
B0102	Main Aux Power Supply Card	1
B0121	Driver Boost Card	3
B0122	Signal Control Card	1
B0124	LEM Boost Card	3
B0125	Input Card	3
B0126	Output Card	3
B0127	Aux 24V Power Supply Card	1
B0132	Adapter CB 20A card	1
B0133-01. / B0133-03.	Filter Input Card	1
B0133-02. / B0133-04.	Filter Output Card	1
B0135	Driver Inverter Card	3
B0137	Inverter Card	3
B0138	PFC Card	3
B0144	LEM inverter Card	3
B0155	Cond. CY BATTERY Card	1
B0156	Cond. CY N Card	1
B0180	Capacitor Elect. x4 Card	3
B0181	Filter Card CY IN/OUT/BY	3
B0182	Filter Card CY N	1
B0183	Capacitor Elect. x2 Card	3